



Painting Floor Tiles with Temadur 20

- First wash the floor with a strong detergent. A rough pad should be used to scrub the whole floor, paying particular attention to areas where dirt can build up such as grout lines, cracks in the tiles and corners. These may look clean but there can be contaminants on a microscopic level.
- After you have washed with the detergent you should give another deep clean with fresh water to ensure there is no residue from the cleaning agent.
- Following the wash you should give the whole floor a light sand. This takes any glossiness from the surface and aids adhesion of the paint.
 - Once sanding has been completed you should remove all sanding dust. This can be done with a vacuum cleaner to take up the heavy dust followed by a wipe with a damp mop.
 - Allow 24hrs to dry after washing. The floor may look dry but there can still be moisture in cracks and the grout lines.
 - Once the floor has been given time to dry you can apply your priming coat.
 - Allow at least 6hrs for the first coat to dry before applying the second coat.
 - Let the paint cure for 24hrs before use.
 - The surface should be treated with caution for the first 7 days as it takes roughly this time to fully cure.